





No.	Code	Name	No.	Code	Name
1	617012	SCREW	39	617063	DEPTH OF DRIVE ASSEMBLY
2	617013	FLAT WASHER	40	617064	STEP PIN
3	617014	EXHAUST COVER	41	617065	CHECK PAWL
4	617015	SCREW	42	617066	COMPRESSION SPRING
5	617322	CAP ASSEMBLY	43	617329	DOOR
6	617017	SPACER	44	617068	SLEEVE
7	617018	PISTON STOP	45	617069	DOOR TORSION SPRIN
8	617019	COMPRESSION SPRING	46	617071	STRAIGHT PIN
9	617021	O RING	47	617330	CONTACT ARM COVER
10	617022	PISTON HEAD VALVE	48	617073	FLAT WASHER
11	617023	O RING	49	617074	SCREW
12	617024	COLLAR	50	617075	BUMPER
13	617025	CYLINDER CAP SEAL	51	617076	O RING
14	617026	O RING	52	617077	O RING
15	617323	DRIVER ASSEMBLY	53	617331	NOSE ASSEMBLY
16	617324	CYLINDER ASSEMBLY	54	617079	SCREW
17	617029	O RING	55	617081	ROLLED PIN
18	617031	O RING	56	617082	FEED PAWL
19	617032	CYLINDER RING	57	617332	FEED PISTON
20	617033	O RING	58	617084	O RING
21	617034	O RING	59	617085	FEED PISTON STOP
22	617325	BODY	60	617086	COMPRESSION SPRING
23	617036	ROLLED PIN	61	617087	SPRING COLLAR
24	617037	ROLLED PIN	62	617088	C RING
25	617038	STEP PIN	63	617089	TORSION SPRING
26	617039	GASKET	64	617091	STOPPER
27	617041	END CAP, BLACK	65	617092	SCREW
28	617042	SCREW	66	617093	DUO-FAST LOGO LABE
29	617052	TRIGGER VALVE ASSE	67	617094	DUO-FAST LOGO LABE
30	617053	SPRING	68	617095	O RING
31-1	617333	BUMP FIRE TRIGGER	69	617096	O RING
31-2	575193	SEQUENTIAL FIRE TRIGGER	70	617097	WAVE WASHER
32-1	617326	MAGAZINE COMPLETE, BUMP FIRE	71	617098	SCREW
32-2	617352	MAGAZINE COMPLETE, SEQUENTIAL	72-1	575176	MODEL LABEL, BUMP FIRE
34	617057	LOCK NUT	72-2	575188	MODEL LABEL, SEQUENTIAL
35	617058	RUBBER WASHER	73	575167	WARNING LABEL
36	617327	STEP PIN	74	617241	AIR PLUG
37	617328	SAFETY ASSEMBLY	76	402486	PU RING
38	617062	RUBBER PAD			