





No.	Code	Name	No.	Code	Name
1	617539	Screw	38	617493	End cap
2	617558	Bushing	39	617529	Pin
3	617504	Exhaust Cover	40	617517	Bushing
4	617533	Screw	41	617495	Lock
5	617535	Washer	42	617515	Spring
6	617489	Cylinder Cap	43	617557	Support
7	617550	Gasket	44	617490	Driver guide
8	617548	Seal	45	617499	Work Piece Contact
9	617519	Spring	46	617554	No Mar Tip
10	617521	O-ring	47	617492	Plate
11	617510	Valve	48	617530	Pin
12	617527	O-ring	49	617491	Front plate
13	617507	Piston Stop	50	617547	Washer
14	617552	Restrict washer	51	617532	Screw
15	617551	Cylinder Seal	52	617542	Pin
16	617484	Piston Unit	53	617496	Rail
17	617523	O-Ring	54	617486	Fixed Magazine Unit
18	617505	Cylinder	55	617487	Movable magazine Unit
19	617524	O-ring	56	617512	Cover
20	617525	O-ring	57	617556	Cover
21	617503	Collar	58	617511	Rear Plate
22	617522	O-ring	59	617536	Nut
23	617506	Bumper	60	617538	Screw
24	617508	Joint guide	61	617518	Spring
25	617526	O-ring	62	617520	Guide
26	617545	Logo-1	63	617497	Pusher
27	617488	Body	64	617531	Screw
28	617485	Trigger Valve Unit	65	617494	Support
29	617514	Spring	66	617528	Pin
30	617501	Trigger Unit (contact)	67	617540	Screw
30	617502	Trigger Unit (sequential)	68	617541	Pin
31	617553	Safety Bracket	69	617516	Spring
32	617537	Spring Pin	70	617555	Lock
33	617513	Spring	71	617509	Air Plug
34	617498	Safety braket A	72	617534	Washer
35	617500	Safe bracket B	73	575493	Type Label (sequential)
36	617544	Logo-2	73	575495	Type Label (contact)
37	617549	Gasket			