





No.	Code	Name	No.	Code	Name
01	617920	CAP ASS.	44	576318	FLAT SPRING
02	617539	SCREW	45	576319	SPRING
03	617558	BUSHING	46	576320	ACTUATOR
04	617504	EXHAUST COVER	47	576321	INDICATOR
05	617548	SEAL	48	576323	SPRING
06	615719	SPRING	49	617927	PIN
07	617521	O RING	50	617928	SCREW
08	617510	PISTON HEAD VALVE	51	617073	WASHER
09	617527	O RING	52	576325	STOPPER
10	617507	PISTON STOPPER	53	576326	SPRING
11	617550	GASKET	54	617077	O RING
12	576351	DRIVER ASS.	55	576361	O RING
13	576352	O RING	56	576327	SPRING
14	617552	CYLINDER SEAL	57	576362	SCREW
15	617551	WASHER	58	576363	WASHER
16	576353	CYLINDER ASS.	59	576328	LEVER
17	617524	O RING	60	617095	O RING
18	576354	CYLINDER RING	61	576329	FEED PAWL
19	617522	O RING	62	617081	PIN
20	617525	O RING	63	576330	FEED PISTON
21	617921	BUMPER	64	617084	O RING
22	617529	PIN	65	617631	SPRING
23	617922	BODY	66	617085	FEED PISTON STOP
24	617526	O RING	67	617087	SPRING COLLAR
25	617529	PIN	68	617088	C RING
26	617549	GASKET	69	576322	PU RING
27	576355	END CAP	70	576331	CHECK PAWL
28	576356	SCREW	71	617058	RUBBER WASHER
29	617138	SCREW	72	576332	SPRING
30	617057	LOCK NUT	73	576348	DOOR
31	617485	TRIGGER VALVE	74	576334	PIN
32	617514	SPRING	75	576335	SLEEVE
33	617502	SEQUENTIAL TRIGGER	76	617069	SPRING
33	575920	CONTACT TRIGGER KIT	77	617071	PIN
34	576357	GUIDANCE	78	617042	SCREW
35	576358	SPRING	79	576349	MAGAZINE ASS.
36	617498	BRACKET	80	575902	MODEL LABEL SEQUENTIAL
37	576359	UPPER WPC	80	575914	MODEL LABEL CONTACT
38	617137	SCREW	81	576364	SCREW
39	576314	SCREW	82	576338	AIR PLUG
40	576226	WASHER	83	576350	SAFETY LEVER
41	576346	COVER	84	576340	RUBBER PAD
42	576360	NOSE ASS.	85	576341	SAFETY TIP ASS.
43	576317	STOP LEVER			