





No.:	Code:	Name:	No.:	Code:	Name:
1	617539	Screw	29	576147	Spring
2	617558	Bushing	30	617498	Safe Bracket
3	617504	Exhaust Cover	31	576148	Safe Bracket B
4	617533	Screw	32	617529	Trigger Pin
5	617535	Spring Washer	33	617485	Trigger Valve Unit
6	576142	Cylinder Cap	34	617501	Trigger Unit
7	617550	Gasket	35	576150	Nose Unit
8	617548	Seal	36	576151	Screw
9	617519	Spring	37	576153	Workpiece Contact
10	617521	O-Ring	38	576154	Spring
11	617510	Valve	39	576156	Pusher Unit
12	617527	O-Ring	40	576161	Screw
13	617507	Stopped Washer	41	576163	Pusher Lock
14	617552	Restrict Washer	42	576164	Button
15	617551	Cylinder Seal	43	576165	Spring
16	576144	Piston Unit	44	576166	Spring
17	617523	O-Ring	45	576174	Magazine Cover Unit
18	617505	Cylinder	46	617549	Gasket
19	617524	O-Ring	47	576167	Nut
20	617525	O-Ring	48	576168	End Cap
21	617503	Restrictive Plate	49	617534	Washer
22	617522	O-Ring	50	576169	Screw
23	617506	Bumper	51	617509	Air Plug
24	617508	Joint Guider	52	576177	Pin
25	576146	Body Unit	53	576171	Staple Catch Set
26	617526	O-Ring	54	575856	Sequential Trigger Unit
27	617537	Spring Pin	55	575855	Model Label Sequential
28	617553	Safe Bracket Guider	56	575854	Model Label Contact