





No.	Code	Name	No.	Code	Name
1	617305	SCREW	40	617353	SCREW
2	617161	FLAT WASHER	41	615906	SET PLATE
3	617342	EXHAUST COVER	42	904690	SCREW
4	617306	PU RING	43	615905	NOSE PN765
5	617164	SLEEVE	44	615903	DRIVER GUIDE COVER
6	617343	SCREW	45	615901	STEPPED PIN
7	615868	SPACER	46	615931	LATCH
8	615869	PISTON STOPPER	47	403713	E RING
9	615927	SPACER	48	617354	NOSE ASSEMBLY PN765
10	615870	SPRING	49	617355	SCREW
11	615871	O RING	50	004238	SPRING WASHER
12	617344	PISTON HEAD VALVE	51	617356	COVER
13	615873	O RING	52	617357	SCREW
14	615874	SEAL	53	615917	BRACKET
15	617345	CAP ASSEMBLY	54	615938	LOCK NUT
16	615875	O RING	55	615909	POSITIONING BUSHING
17	615929	PISTON ASSEMBLY PN765	56	615908	MAGAZINE PN765
18	615876	CYLINDER SPACER	57	402167	SCREW
19	615877	O RING	58	615912	PUSHER PN765
20	615878	O RING	59	617359	SCREW
21	615930	O RING	60	615913	SPRING
22	617269	O RING	61	615923	ROLLER
23	617346	CYLINDER ASSMEBLY	62	617360	ROLLED PIN PN765
24	615880	BUMPER	63	617361	SHAFT
25	615881	WASHER PN765	64	615916	SPRING
26	615883	GASKET	65	615915	STOPPER
27	615885	STEPPED PIN	66	401254	LOCK NUT
28	617347	BODY	67	615926	STAR WASHER
29	615918	GASKET	68	617362	SCREW
30	617188	END CAP	69	615925	SAFETY ADJUSTING LEVER
31	617348	AIR PLUG	70	615889	SAFETY LEVER
32	615936	SCREW	71	615941	SCREW
33	615940	SCREW	72	615924	UPPER SAFETY LEVER
34	402486	PU RING	73	615887	GUIDE SAFETY LEVER
35	617349	TRIGGER ASSEMBLY contact PN765	74	615888	COMPRESSION SPRING
36	615902	SPRING	75	617363	LOGO LABEL
37A	615933	BUMP FIRE TRIGGER	76A	574513	MODEL LABEL PN765 contact
37B	575191	SEQUENTIAL FIRE TRIGGER	76B	574515	MODEL LABEL PN765 sequential
38	615922	GASKET	77	574516	WARNING LABEL
39	615886	BOTTOM			

No.	Code	Name	No.	Code	Name
1	617305	SCREW	40	617353	SCREW
2	617161	FLAT WASHER	41	615906	SET PLATE
3	617342	EXHAUST COVER	42	904690	SCREW
4	617306	PU RING	43	615904	NOSE PN7965
5	617164	SLEEVE	44	615903	DRIVER GUIDE COVER
6	617343	SCREW	45	615901	STEPPED PIN
7	615868	SPACER	46	615931	LATCH
8	615869	PISTON STOPPER	47	403713	E RING
9	615927	SPACER	48	617350	NOSE ASSEMBLY PN7965
10	615870	SPRING	49	617355	SCREW
11	615871	O RING	50	004238	SPRING WASHER
12	617344	PISTON HEAD VALVE	51	617356	COVER
13	615873	O RING	52	617357	SCREW
14	615874	SEAL	53	615917	BRACKET
15	617345	CAP ASSEMBLY	54	615938	LOCK NUT
16	615875	O RING	55	615909	POSITIONING BUSHING
17	615928	PISTON ASSEMBLY PN7965	56	615907	MAGAZINE PN7965
18	615876	CYLINDER SPACER	57	617358	SCREW
19	615877	O RING	58	615911	PUSHER PN7965
20	615878	O RING	59	617359	SCREW
21	615930	O RING	60	615913	SPRING
22	617269	O RING	61	615923	ROLLER
23	617346	CYLINDER ASSMEBLY	62	310088	ROLLED PIN PN7965
24	615880	BUMPER	63	617361	SHAFT
25	615882	WASHER PN7965	64	615916	SPRING
26	615883	GASKET	65	615915	STOPPER
27	615885	STEPPED PIN	66	401254	LOCK NUT
28	617347	BODY	67	615926	STAR WASHER
29	615918	GASKET	68	617362	SCREW
30	617188	END CAP	69	615925	SAFETY ADJUSTING LEVER
31	617348	AIR PLUG	70	615889	SAFETY LEVER
32	615936	SCREW	71	615941	SCREW
33	615940	SCREW	72	615924	UPPER SAFETY LEVER
34	402486	PU RING	73	615887	GUIDE SAFETY LEVER
35	617349	TRIGGER ASSEMBLY contact PN765	74	615888	COMPRESSION SPRING
36	615902	SPRING	75	617363	LOGO LABEL
37A	617351	BUMP FIRE TRIGGER	76A	574518	MODEL LABEL PN7965 contact
37B	575192	SEQUENTIAL FIRE TRIGGER	76B	574520	MODEL LABEL PN7965 sequential
38	615922	GASKET	77	574516	WARNING LABEL
39	615886	BOTTOM			