



No.	Code	Name	No.	Code	Name
01	613514	CAP ASM.	38	613523	NOSE COVER
02	613100	FLAT HD. BOLT	39	613520	PLATE MOUNT
03	613002	FRONT BRACKET	40	613531	RUBBER PAD
04	613003	EXHAUST COVER	41	613028	RUBBER GRIP
05	613004	EXHAUST FILTER	42	613029	O-RING
06	613005	EXHAUST FILTER PLATE	43	613400	COVER
07	623149	HEX.SOC.HD.BOLT	44	391210	AIR NIPPLE
08	613102	SPRING	45	613031	ROLLED PIN
09	613103	O-RING	46	613123	SEQUENTIAL TRIGGER grey
10	613104	PISTON HEAD VALVE	46	613101	CONTACT TRIGGER orange
11	613105	O-RING	47	613053	SPRING
12	613106	SEAL	48	613124	SWITCH ASM.
13	613107	PLAIN WASHER	49	613055	TRIP GUIDE
14	613108	PISTON STOPPER	50	613056	SPRING
15	613110	O-RING	51	613058	CONTACT TRIP BLOCK
16	613515	DRIVER ASSEMBLY	52	613135	SPIRAL SPRING ASM.
17	613516	CYLINDER	53	613530	PUSHER ASM.
18	613113	O-RING	54	613526	PUSHER
19	613114	CYLINDER RING	55	613060	SPRING
20	613115	COLLAR	56	613527	PUSHER STOPPER
21	613116	O-RING	57	613138	ROLLED PIN
22	613117	GASKET	58	613528	ROLLED PIN
23	613517	BODY	59	613529	PUSHER GUIDE
24	574493	LOGO LABEL	60	623149	HEX.SOC.HD.BOLT
25	613025	O-RING	61	613149	FLAT WASHER
26	613119	UP BUMPER	62	574426	LOCK NUT
27	613120	BOTTOM BUMPER	63	613537	MAGAZINE ASM.
28	613518	SET PLATE	64	613147	LOCK NUT
29	613121	O-RING	65	613534	BRACKET
30	613524	NOSE ASM.	66	613536	MAGAZINE
31	613519	NOSE	67	613532	MAGAZINE COVER
32	613525	HEX.SOC.HD.BOLT	68	613533	NAIL STOPPER
33	613128	SPRING	69	613535	NAIL GUIDE LINER
34	613521	UPPER SAFETY LEVER	70	613071	UM.HD.BOLT
35	613522	SAFETY LEVER	71	505920	MODEL LABEL sequential
36	613132	FLAT WASHER	71	505921	MODEL LABEL contact
37	613131	HEX.SOC.HD.BOLT	72	613099	WARNING LABEL